

How do we calculate R?


Ohm's Law tells us that in a conductor, the voltage and current are proportional to each other (within some useful range). That is,

$$v = i \cdot R \quad (\Omega)$$

where the proportionality constant, R , is called **resistance** and has the units of Ohms (Ω).

In general, resistance is a function of *material properties* and *geometry of the conductor*.

A long, cylindrical wire provides a good example and other geometries have similar (although sometimes much more complex) equations.



The wire in this example has a material property called **conductivity**, σ , which is a measure of how much obstruction the material's atoms present to moving electrons. The units of σ is Siemens / m. A Siemens (S) is just the reciprocal of the ohm (Ω). Amusingly, before being standardized, the Siemens was often called the *mho*.

The resistance, R , can be calculated from:

$$R = \frac{\ell}{\sigma A} \quad (\Omega)$$

Note:

- the higher the conductivity, the lower the resistance
- the larger the cross sectional area, the lower the resistance
- the longer the wire, the higher the resistance

The reciprocal of conductivity provides the same information and is often cited instead. This is called the resistivity, ρ , and has units of $\Omega \cdot m$.

$$\rho = \frac{1}{\sigma} \quad (\Omega \cdot m)$$